


5.7. Komfortanh. 2°C

5.8. Soll/Ist - 0°C

5.9. Soll/Ist + 1°C



Info



WPC 5

Wärmepumpen Controller